


Części niezbędne do skonstruowania oprawy na bazie profilu KUBIK-45



Profil (A)



Osłona (B)



Taśma LED (C)



Łącznik wzdłużny (D)



Łącznik kątowy pionowy (E)



Łącznik kątowy poziomy (F)


Elementy niezbędne przy czynnościach montażowych:

- wiertarka
- piła do metalu
- lutownica do taśm LED

UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Włóż osłonę (B) w profil (A).




2. Potnij profil (A) na wybrane odcinki razem z osłoną, pod odpowiednimi kątami do łączenia wzdłuż, w płaszczyznach prostopadłych lub do tworzenia „trójników".

przykłady:






3. Wyjmij osłony z otrzymanych odcinków profilu (A) i nawierć otwór na przewody zasilające w wybranym z nich.




4. Wklej taśmy LED (C), do odcinków profilu (A) i wyprowadź przewód zasilający.





5. Połącz odcinki profilu (A) przy uzyciu odpowiednich łączników (D, E, F). Pobierz instrukcję łączników ze strony klusdesign.pl Połącz lutownicą poszczególne odcinki taśmy LED.

przyklad:



6. Włóż ponownie osłony (B) do poszczególnych odcinków profilu (A).





Parts needed to mount the KUBIK-45 extrusion



Extrusion (A)



Cover (B)



LED strip (C)



Straight connector (D)



Vertical angled connector (E)



Horizontal angled connector (F)


Tools needed for mounting:

- drill
- metal saw
- soldering tool for LED

WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly.
More methods and related accessories can be found at


1. Insert the cover (B) into the extrusion (A).




2. Cut the extrusion (A) into sections together with the cover, at angles appropriate for lengthwise connection, in vertical planes, or T-connections.

examples:






3. Remove the covers from the obtained sections of the extrusion (A) and drill a hole for the power cables into one of them.




4. Mount the LED strips (C) in the segments of the extrusion (A) and lead out the power cable.



5. Connect the sections of the extrusion (A) with appropriate connectors (D, E, F). Download the connector manual at KlusDesign.eu Solder the sections of LED strips together.

examples:



6. Insert the covers (B) into the individual sections of the extrusion (A) again.

