



Części niezbędne do złożenia i wykorzystania zawieszki PUSZ-PRET-MR

Nakrętka z podkładką (I)



Nakrętka górna (H)



Podkładka koronkowa (G)



Łącznik prądowy (F)




Nakrętka dolna (E)




Podkładka mała (D)



Puszka z tuleją (C)



Gwintowany korek (B)



Śruba (A)




Elementy niezbędne przy czynnościach montażowych:

- klucz ampulowy
- wiertarka
- kombinerki


UWAGA! Lista produktów, z którymi współpracują wybrane akcesoria dostępna jest na stronie .

1. Wywierć w grzbiecie profilu otwory o średnicy 6mm. Po jednym otworze na zawieszkę.




ø 6mm

2. Umieść gwintowany korek (B) nad nawierconym otworem i dokręć do niego od spodu śrubę (A). Następnie przeprowadź przewód z jednym biegunem prądu przez otwór w śrubie i wklej taśmę LED do profilu.




3. Przełóż przewód przez podkładkę małą (D) i nałóż na całość puszkę (C). Dokręć puszkę na gwincie by zablokować ruch zawieszki.



4. Załóż łącznik prądowy (F) na końcówkę przewodu.




5. Zegnij łącznik prądowy (F) tak by wszedł do wnetrza puszki (C). Przełóż nagwintowany pręt przez łącznik i zabezpiecz go nakrętkami (E, H) i podkładką koronkową (G).




6. Nałóż nakrętkę (I) od górnej części pręta.




7. Wsuń całość do puszki i dokręć nakrętkę.



8. Podwieś oprawę na wybranym systemie mocowania.





Parts needed to mount the PUSZ-PRET-MR fastener

Nut with washer (I)

Top nut (H)

Locking washer (G)

Power connector (F)

Bottom nut (E)

Small washer (D)

Sleeve (C)

Threaded plug (B)


Bolt (A)

Tools needed for mounting:

- Allen wrench
- drill
- pliers


NOTE! A list of products corresponding with the selected accessories is available

1. Drill holes with a diameter of 6mm in the back of the extrusion. One hole per fastener.




ø 6mm


2. Insert the threaded plug (B) over the drilled hole and tighten the bolt (A) at the bottom. Run a cable with one pole through the hole in the bolt and mount the LED strip in the extrusion.




3. Run the cable through the small washer (D) and put the sleeve (C) on the entire assembly. Tighten the sleeve on the arm with thread to stop the fastener from moving.



4. Attach the power connector (F) to the cable end.




5. Bend the power connector (F) so that it fits into the sleeve (C). Put an arm with thread through the connector and secure it with nuts (E, H) and a toothed washer (G).



6. Pull the nut (I) on from the top side of the arm.



7. Insert the entire assembly into the sleeve and tighten the nut.



8. Suspend the lighting fixture using a selected suspension system.

