



1. MICRO-PLUS profile (Ref. C2966)
2. LED strip*
3. End cap*
4. Cover*
5. End cap with hole*
6. Countersunk screw 6-8 mm / 0.24-0.31” - not included*
7. Mounting bracket*
8. Power supply (12 V / 24 V)*

*The full range of accessories and electronics is available

NOTE! All LED tapes must be connected to a 12 V or 24 V power supply.


IMPORTANT: Not all possible mounting procedures are presented here.
More mounting procedures and related accessories can be found
Drawings of extrusions and accessories in these instructions are simplified and only approximate the actual shapes.

I



Attach the mounting bracket (7) to the surface with appropriate screws (6).


II



Mount the LED tape (2), end caps (3, 5) and the cover (4) in the MICRO-PLUS profile (1).

Lead the cable from the LED tape through the end cap with hole (5) and connect it to power supply 12 V / 24 V (8).


III



Snap the lighting fixture into the brackets.


To faciliate the procedure, use a small screwdriver to bend the bracket's flange outwards, before inserting the fixture.

Montaż oprawy podwieszanej na bazie profilu MICRO-PLUS
sufit kartonowo-gipsowy




Instrukcja przedstawia następujące metody montażu:

1) Na pręcie - zasilanie poprzez system podwieszenia z zewnętrznym złączem prądowym



2) Na pręcie - zasilanie zewnętrzne (osobny przewód)



Elementy niezbedne przy czynnosciach montażowych:

- wiertarka
- kombinerki
- klucz imbusowy
- lutownica


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie

Montaż oprawy podwieszanej na bazie profilu MICRO-PLUS
1. Na pręcie - zasilanie poprzez system podwieszenia

1. Nawierć 2 otwory o średnicy 5 mm w profilu, żeby wyprowadzić przewód zasilający.

przekrój




Fi 5 mm

widok z dołu




2. Wepnij gotową oprawę w mocownik głowicy. Pobierz instrukcję dla zawieszki DP-MOC-ZZ ze strony




3. Wklej taśmę LED w profil i wyprowadź przewody zasilające przez nawiercone wcześniej otwory. Następnie podłącz je do łączników w zawieszkach DP-MOC--ZZ. Przez pojedynczy otwór powienien przechodzić przewód z jednym biegunem prądu. Taśma LED musi zostać przecięta przed montażem, żeby przewody można było łatwo wprowadzić przewody w otwory.

przekrój




widok z dołu

Należy zlutować biegun dodatni




Należy zlutować biegun ujemny


4. Zainstaluj pręt, osłonkę i zaślepkę.



5. Zainstaluj zawieszki W-KG-Z. Pobierz instrukcję zawieszki ze strony Podłącz przewody, po jednym biegunie prądu do każdej zawieszki. Kable należy przeprowadzić przez nawiercony wcześniej otwór w suficie, ukryty pod maskownicą zawieszki.




6. Zamontuj oprawę z prętami w zawieszkach sufitowych. Zwróć uwagę żeby bieguny prądu podłączone do prętów odpowiadały biegunom przy zawieszkach.



Montaż oprawy podwieszanej na bazie profilu MICRO-PLUS
2. Na pręcie - zasilanie zewnętrzne (wymaga osobnego przewodu)

1. Nawierć otwór o średnicy 5 mm w profilu, żeby wyprowadzić przewód zasilający.

przekrój




Fi 5 mm

widok z dołu



2. Wepnij gotową oprawę w mocownik głowicy. Pobierz instrukcję dla zawieszki DP-MOC ze strony




3. Wklej taśmę LED w profil i wyprowadź przewody zasilające przez nawiercony wcześniej otwór.


przekrój




widok z dołu




4. Zainstaluj pręt, osłonkę i zaślepkę.




5. Zainstaluj zawieszki sufitowe W-KG. Pobierz instrukcję instalacji zawieszki ze strony Umieść zasilacz obok zawieszki i nawierć sufit tak, by przeprowadzić przewód zasilający.



6. Zamontuj oprawę z prętami w zawieszkach sufitowych. Podłącz przewód zasilający.






1. MICRO-PLUS profile (Ref. C2966)
2. LED strip*
3. End cap*
4. Cover*
5. End cap with hole*
6. Countersunk screw 6-8 mm / 0.24-0.31” - not included*
7. Mounting bracket*
8. Power supply (12 V / 24 V)*

*The full range of accessories and electronics is available

NOTE! All LED tapes must be connected to a 12 V or 24 V power supply.


IMPORTANT: Not all possible mounting procedures are presented here.
More mounting procedures and related accessories can be found
Drawings of extrusions and accessories in these instructions are simplified and only approximate the actual shapes.

I



Attach the mounting bracket (7) to the surface with appropriate screws (6).


II



Mount the LED tape (2), end caps (3, 5) and the cover (4) in the MICRO-PLUS profile (1).


Lead the cable from the LED tape through the end cap with hole (5) and connect it to power supply 12 V / 24 V (8).

III




Snap the lighting fixture into the brackets.

To faciliate the procedure, use a small screwdriver to bend the bracket's flange outwards, before inserting the fixture.




Instruction includes methods of montage:

Rod - conductive driven power supply, with an external power connector



2) Rod - non-conductive (drop lead)



Tools needed for mounting:


- drill
- pliers
- allen wrench
- soldering iron

NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure.
More mounting procedures and related accessories can be found

1. Drill 2 holes with a diameter of 5 mm in the selected extrusion to lead the power cables.

cross-section




Fi 5 mm

bottom view




2. Insert the extrusion into the mounting bracket of the head. Manual for the DP-MOC-ZZ fastener can be downloaded from




3. Mount the LED strip in the extrusion and lead the cables through pre-drilled smaller holes. Then lead them to the connectors of the DP-MOC-ZZ fasteners. Each hole should lead a cable with one power pole, LED strip has to be cut before installation, so the wires can be easily routed to the holes.

cross-section




bottom view

Positive pole has to be soldered




Negative pole has to be soldered


4. Install the rod, cover and both end caps.



5. Install the W-KG-Z ceiling fasteners. The fastener installation manual can be downloaded Connect the cables, each for the single power pole to the fasteners. The cables should go through a pre-drilled hole just under the masking cover of the fastener.




6. Mount the fixture with rods into the ceiling fasteners. Mind that the power poles connected to the rods should match the ones connected to the fasteners.



1. Drill a hole with a diameter of 5 mm in the selected extrusion to lead the power cable.

cross-section




Fi 5 mm

bottom view



2. Insert the extrusion into the mounting bracket of the head. Manual for the DP-MOC fastener can be downloaded from




3. Mount the LED strip in the extrusion and lead the cable through a pre-drilled hole.


cross-section




bottom view



4. Install the rod, cover and both end caps.



5. Install the W-KG ceiling fasteners. The fastener installation manual can be downloaded . Place the power supplier next to the fastener and drill the ceiling to lead the cable to it.



6. Mount the fixture with rods into the ceiling fasteners. Connect the powering cable.

