


Części niezbędne do skonstruowania oprawy na bazie profilu PDS-4-ALU



Mocownik (A)



Profil (B)



Zaślepka (C)



Taśma LED (D)



Osłona (E)


Elementy niezbędne przy czynnościach montażowych:

- wiertarka
- wkrętarka / śrubokręt
- wkręty


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Wyprowadź przewód zasilający. Przykręć mocownik (A) do powierzchni.




2. Wklej taśmę LED (D) w profilu (B), załóż osłonę(E) i zaślepkę (C).



3. Podłącz zasilanie do paska LED i umieść profil (B) w mocowniku (A). Istnieją dwie możliwości podłączenia zasilania przez otwór w profilu lub przez zaślepkę.





Parts needed to mount the PDS-4-ALU extrusion



Mounting bracket (A)



Extrusion (B)



End cap (C)



LED strip (D)



Cover (E)


Tools needed for mounting:

- drill
- screwdriver
- screws


WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly.
More methods and related accessories can be found

1. Feed the power cable. Attach the mounting bracket (A) to the mounting surface with screws.



2. Mount the LED strip (D) in the extrusion (B), insert the cover (E) and the end cap (C).



3. Connect power to the LED strip and mount the extrusion (B) in the mounting bracket (A). There are two ways to connect power: through a hole in the extrusion or through the end cap.

